



*ELECTRONIC ENGINEERING LTD.*

# Runner Series

WIRELESS AND WIRED CONTROL PANEL

Technician's  
Handbook

**Version 9.08.2**

## **IMPORTANT NOTICE**

All information and data contained in this document is proprietary and confidential. CROW Electronic Engineering Ltd. shall not be liable, in any event, for any claims for damages or any other remedy in any jurisdiction whatsoever, whether in an action in contract, tort (including negligence and strict liability) or any other theory of liability, whether in law or equity including, without limitation, claims for damages or any other remedy in whatever jurisdiction, and shall not assume responsibility for patent infringements or other rights to third parties, arising out of or in connection with this document.

Further, CROW Electronic Engineering Ltd. reserves the right to revise this publication and to make changes to its content, at any time, without obligation to notify any person or entity of such revision changes. These materials are copyrighted and any unauthorized use of these materials may violate copyright, trademark, and other laws. Therefore, no part of this publication may be reproduced, photocopied, stored on a retrieval system, or transmitted without the express written consent of CROW Electronic Engineering Ltd. Any new issue of this document invalidates previous issues.

**©CROW Electronic Engineering Ltd. 2005. All rights reserved.**

Information in this document is subject to change without notice. No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, without express written permission of CROW Electronic Engineering Ltd..

# How to Use this Handbook

---

The following program summary is an abridged version of all the Installation Guide describing the panel program addresses. This is intended as a quick guide for finding a program address and entering parameters quickly. In many address locations, there is a main address (for example, **P1E**), then a sub address (for example, **P1E 1E**). You must first enter the main address number, followed by the sub address, and then you can enter or set the actual parameters. The program addresses are in numerical order making them easy to find.

## ◆ To view the program parameters:

1. Press the **Program** key.
2. Enter the **Address** from the tables below.
3. Press the **Enter** key.

The parameters for this address are displayed.  
Example, **1 - - 4 5 6 - 8**.

## ◆ To change the program parameter defaults:

1. Press the **Program** key.
2. Enter the **Address** from the tables below.
3. Press the **Enter** key.
4. Enter data or a numerical key to change the parameter.
5. Press the **Enter** key.

Column	Description
<b>Address</b>	Program address
<b>Def</b>	Parameter default ✓ = on
<b>New</b>	Your configuration setting (use pencil)
<b>Opt.</b>	Parameter number
<b>SEQ</b>	Sequence step number
✓	Default on all
✓*	Default <b>NOT</b> on all



# Runner Series Quick Start Guide

The default settings of this panel have been chosen to allow the system to be up and running with a minimum of programming. Because of this there are normally only a handful of program addresses that need to be changed to get the system fully functional.

As a guide to getting the system up and running as quickly as possible we have summarised the most commonly used addresses for you below.

Just in case, you can always return the unit to the factory defaults, see **P200E** 45.

## Programming the Unit

### Step 1: Program the Keypad

The detailed instructions can be found in the Installation and Programming Guide.

- Set keypad address assignments as each keypad connected to the system must have a unique address
- Set the language (choose from those available)
- Edit the default zone, area, user and output names if required

### Step 2: Program the User Codes

Address	Description
<b>P1E 1-100E</b>	Set the user code (password). Code 1 is P1E1E and defaults to 1234. This means that User 1 automatically gets the code 1234. Code 2 is P1E2E, this continues up to P1E100E for user 100.

### Step 3: Set the Clock

Address	Description
<b>P26E</b>	Set the hour and date.

### Step 4: Program the Zones

The panel uses two kinds of zones, hardwired and wireless.

#### Programming Hardwired Zones

SEQ	Address	Remarks/Example
<b>1</b>	<b>P122E 1-16E</b> Runner-4 <b>1-8E</b>	Set the zones in use as active Turn on option 1 (zone active).
<b>2</b>	<b>P121E 1-16E</b> Runner-4 <b>1-8E</b>	Select zone area assignment.
<b>3</b>	<b>P125E 1-8E</b> Runner-4 <b>1-4E</b>	Set zone type (hardwired) NC, EOL or double zone.

## Programming Wireless Zones

SEQ	Address	Remarks/Example
1	P122E 1-16E	Set the zones in use as active. Turn on option 1 (zone active).
2	P121E 1-16E.	Select zone area assignment.
3	P122E	Set the zone type (radio zone = option 5).
4	P127E	Set radio zone detector type.
5	P164E	Learn (Recognize) the detector. For a detailed explanation see the Learn Radio Zone Codes section.

## Step 5: Dialler and Telephone Numbers

SEQ	Address	Remarks/Example
1	P175E 1E	By default the Dialler is turned On. To turn Off the dialler, you must turn off Option 1 at address P175E1E.
2	P175E 3E	Set auto ring count. This is in case the dialled number has an answering service that only answers after a predetermined number of rings.
3	181E 1-8E	Program the phone numbers.
4	P182E 1-8E	Set the reporting format.
5	P62E 1-2E	In cases where the CID reporting format is used, program the account code.

## Step 6: Assigning the Keypad Area

Address	Description
P71E 1-8E	Assign the keypad to the correct area.

## Step 7: Program the Pendants

SEQ	Address	Remarks/Example
1	P2E 21-100E	Set the user as a radio user. Enter a 1 for crow pendants.
2	P18E 21-100E	Recognize the pendant.
3	P7E 21-100E	Set the radio user type. Enter a 1 for crow pendants.
4	P3E 21-100E	Select the pendant area.
5	P4E 21-100E	Set the user access options.
6	P8E 21-100E	Setting pendant privileges.

## Step 8: Programming Proximity Reader

SEQ	Address	Remarks/Example
1	P99E 1-8E	Enable the front panel to Learn the reader.
2	P2E 1-100E	Select a user to be tag user.
3	P21E 1-100E	Learn the tag.
4	P3E 1-100E	Selecting the area for the tag.
5	P4E 1-100E	Setting the user access option.

## Step 9: Armed Entry Delays

Address	Description
<b>P144E 1-16E</b> Runner-4 1-8E	Zone 1 entry delay is P144E1E and can have a value of 0-9999 seconds through to Zone 16 entry delay being at address P144E16E. A value of 0 means there is no delay.

## Step 10: Stay Entry Delays

Address	Description
<b>P145E 1-16E</b> Runner-4 1-8E	Zone 1 entry delay when armed in Stay Mode is P145E1E and can have a value of 0-9999 seconds. The Stay Mode entry delay of Zone 16 is at address P145E16E. A value of 0 means that there is no delay.

## Step 11: Setting the ARMED Exit Delay

Address	Description
<b>P60E 1-2</b>	Area A exit delay is programmed at P60E1E, Area B at P60E2E and can have a value of 0-255 seconds. A value of 0 means that there is no exit delay.

## Step 12: Programming the STAY Exit Delay

Address	Description
<b>P61E 1-2E</b>	Area A Stay Mode exit delay is programmed at P61E1E, Area B at P61E2E and can have a value of 0-255 seconds. A value of 0 means that there is no stay exit delay.





# Installation Summary Tables

---

<b>USERS .....</b>	<b>10</b>
<b>MISCELLANEOUS PANEL &amp; CLOCK SETTINGS .....</b>	<b>14</b>
<b>OUTPUTS .....</b>	<b>16</b>
<b>AREAS.....</b>	<b>18</b>
<b>KEYPADS .....</b>	<b>21</b>
<b>KEYSWITCHES .....</b>	<b>27</b>
<b>ZONES .....</b>	<b>28</b>
<b>TIME ZONES .....</b>	<b>37</b>
<b>DIALLER .....</b>	<b>38</b>

# USERS

Address	Description	Def	New
<b>P1E</b> 1-100	<b>PROGRAMMING USER CODES</b> Example = 1234 codes can be either 1-6 or 4-6 digits depending on the configuration. The 100 user entries can be of mixed types, a keypad Code, Radio or Access key, but cannot exceed 100 entries. See also USER TYPE <b>User 1 Code=1234</b>	✓*	
<b>P2E</b> 1-100E	<b>USER TYPE</b> Code/Radio/Access tag-Card <b>Defaults for user 1-20 = 0</b> <b>Defaults for users 21-40 = 1</b> <b>Defaults for users 41-50 = 2</b> <b>Defaults for users 51-100 = 0</b>		
	<b>0</b> Keypad Code User (PIN)	✓	
	<b>1</b> Radio User (Users 21-100 only)	✓	
	<b>2</b> Access Tag/Card User	✓	
	<b>3</b> Both Code and Access Tag/Card User (Tag + PIN)		
	<b>4</b> Either Code or Access Tag/Card User (Tag or PIN)		
<b>P3E</b> 1-100E	<b>USER AREA ASSIGNMENT</b> <b>User 1-100 = 1</b>		
	<b>1</b> Assigned to Area "A"	✓	
	<b>2</b> Assigned to Area "B"		
<b>P4E</b> 1-100E	<b>USER CODE ACCESS OPTIONS</b> <b>User 1-20 = 1,3,4</b> <b>User 21,26,31,36 = 1</b> <b>User 22,27,32,37 = 3,4</b> <b>User 23,28,33,38 = 2</b> <b>User 24,29,34,39 = (Delay Panic – see P8E)</b> <b>User 25,30,35,40 = None (Not In Use)</b> <b>User 41-100 = 1,3,4</b>		
	<b>1</b> Code can Arm Area	✓*	
	<b>2</b> Code can arm Stay Mode	✓*	
	<b>3</b> Code can Disarm Area	✓*	
	<b>4</b> Code can disarm Stay Mode	✓*	
	<b>5</b> Code is a Security Guard Code		
	<b>6</b> Code will Arm Latchkey Mode		
	<b>7</b> Call Divert Code		
	<b>8</b> User can View Event Memory		

<b>P5E</b> 1-100E	<b>USER CODE ACCESS OPTIONS</b>		
	<b>Defaults for user 1 = 2,3,4,5,6,7,8</b>		
	<b>Defaults for users 2-100 = 1</b>		
	1	User can Change their Code <b>(Default for users 2-100)</b>	✓
	2	User can Change All Codes	✓*
	3	User can Allow Access to Installer Mode/Edit all Codes	✓*
	4	User can Change Telephone Numbers	✓*
	5	User can Change the Clock	✓*
	6	User can Change DTMF Command Codes	✓*
<b>P7E</b> 21-100E	<b>RADIO USER TYPE</b>		
	<b>User 21-100:1</b>		
	0	Generic (general Pendant Type)	
	1	Crow Freelink Pendant	✓
<b>P8E</b> 21-100E	<b>RADIO USER PRIVILEGES</b>		
	<b>User 21,26,31,36 = None</b>		
	<b>User 22,27,32,37 = 1</b>		
	<b>User 23,28,33,38 = None</b>		
	<b>User 24,29,34,39 = 3</b>		
	<b>User 25,30,35,40 = None</b>		
	<b>User 41-100 = 1</b>		
	1	Pendant Can Disarm at All Times	✓*
	2	Pendant Causes Immediate Panic	
3	Pendant Causes Delayed Panic ( 1.5 Sec)	✓*	
4	Pendant only works during entry delay		
5	This User is a dedicated Duress Code		
6	Spare		
7	Spare		
8	Spare		
<b>P9E</b> 1-100E	<b>TIME ZONE ASSIGNED TO A USER</b>		
	<b>Users 1-100=None</b>		
	1	User Controlled by Time Zone # 1	
	2	User Controlled by Time Zone # 2	
	3	User Controlled by Time Zone # 3	
	4	User Controlled by Time Zone # 4	
	5	User Controlled by Time Zone # 5	
	6	User Controlled by Time Zone # 6	
	7	User Controlled by Time Zone # 7	
8	User Controlled by Time Zone # 8		

<b>P10E</b> 1-100E	<b>USER TO KEYPAD ASSIGNMENT</b>		
	<b>User 1-100 :All Keypads</b>		
	1	Can Operate at Keypad # 1	✓
	2	Can Operate at Keypad # 2	✓
	3	Can Operate at Keypad # 3	✓
	4	Can Operate at Keypad # 4	✓
	5	Can Operate at Keypad # 5	✓
	6	Can Operate at Keypad # 6	✓
	7	Can Operate at Keypad # 7	✓
8	Can Operate at Keypad # 8	✓	
<b>P11E</b> 21-100E	<b>RADIO PENDANT PANIC BEEPS TO KEYPAD</b>		
	<b>User 21-100 :All Keypads</b>		
	1	A Radio panic will Beep at Keypad # 1	✓
	2	A Radio panic will Beep at Keypad # 2	✓
	3	A Radio panic will Beep at Keypad # 3	✓
	4	A Radio panic will Beep at Keypad # 4	✓
	5	A Radio panic will Beep at Keypad # 5	✓
	6	A Radio panic will Beep at Keypad # 6	✓
	7	A Radio panic will Beep at Keypad # 7	✓
8	A Radio panic will Beep at Keypad # 8	✓	
<b>P12E</b> 1-100E	<b>USERS TO OUTPUT MASK</b>		
	<b>Users 1-100=None</b>		
	1	User is Mapped to Output # 1	
	2	User is Mapped to Output # 2	
	3	User is Mapped to Output # 3	
	4	User is Mapped to Output # 4	
	5	User is Mapped to Output # 5	
	6	User is Mapped to Output # 6	
	7	User is Mapped to Output # 7	
8	User is Mapped to Output # 8		
<b>P13E</b> 1-100E	<b>USER CAN TURN AN OUTPUT ON</b>		
	<b>Users 1-100=None</b>		
	1	User Can Turn on Output # 1	
	2	User Can Turn on Output # 2	
	3	User Can Turn on Output # 3	
	4	User Can Turn on Output # 4	
	5	User Can Turn on Output # 5	
	6	User Can Turn on Output # 6	
	7	User Can Turn on Output # 7	
8	User Can Turn on Output # 8		

<b>P14E</b> 1-100E	<b>USER CAN TURN AN OUTPUT OFF</b>		
	<b>Users 1-100=None</b>		
	1	User Can Turn off Output # 1	
	2	User Can Turn off Output # 2	
	3	User Can Turn off Output # 3	
	4	User Can Turn off Output # 4	
	5	User Can Turn off Output # 5	
	6	User Can Turn off Output # 6	
	7	User Can Turn off Output # 7	
8	User Can Turn off Output # 8		
<b>P15E</b> 1-100E	<b>RADIO PENDANT PANIC ALARM TO AN OUTPUT</b>		
	<b>Users 21-100=1,2</b>		
	1	Radio panic to Output # 1	✓
	2	Radio panic to Output # 2	✓
	3	Radio panic to Output # 3	
	4	Radio panic to Output # 4	
	5	Radio panic to Output # 5	
	6	Radio panic to Output # 6	
	7	Radio panic to Output # 7	
8	Radio panic to Output # 8		
<b>P16E</b> 1-100E	<b>ARMED BY USER # 4+2 REPORTING CODE</b> 4+2 Arm Code for Users 1-100		
<b>P17E</b> 1-100E	<b>DISARMED BY USER # 4+2 REPORTING CODE</b> 4+2 Disarm Code for Users 1-100		
<b>P18E</b> 21-100E	<b>LEARN RADIO PENDANT CODE</b> Only applies if the User Type P2E is set to 1		
<b>P19E</b> 21-100E	<b>DELETE A SPECIFIC RADIO PENDANT CODE</b> Only applies if the User Type P2E is set to 1		
<b>P20E</b> 0E	<b>FIND RADIO PENDANT MEMORY LOCATION</b> Enter this address and then operate the Radio Pendant to find its user number. Only applies if the User Type, P2E, is set to 1		
<b>P21E</b> 1-100E	<b>LEARN ACCESS TAG/CARD CODES</b> Learn Access Tag/Card Codes for Users 1-100. Only applies if the User Type, P2E, is set to 2, 3 or 4		
<b>P22E</b> 1-100E	<b>DELETE A SPECIFIC ACCESS TAG/CARD CODE</b> Delete a Specific Access Tag/Card Code for Users 1-100. Only applies if the User Type, P2E, is set to 2, 3 or 4		
<b>P23E</b> 0E	<b>FIND AN ACCESS TAG/CARD MEMORY LOCATION</b> <b>Only press 0E when using LED Keypad.</b> Enter this address and then operate the Access Tag/Card to find its user number. Only applies if the User Type, P2E, is set to 2, 3 or 4		

## MISCELLANEOUS PANEL & CLOCK SETTINGS

<b>P25E</b> 1E	<b>INSTALLER CODE</b>	000000	
<b>P25</b> 2E	<b>DURESS DIGIT</b>	0 (disable)	
<b>P25</b> 3E	<b>DIAL REPORT DELAY</b> (0-255 sec)	0	
<b>P25</b> 4E	<b>RADIO DETECTOR SUPERVISED TIMER</b> (0-9999 min)	240 min (4 hours)	
<b>P25</b> 5E	<b>TWO TRIGGER TIMER</b> (0-255 sec)	60 sec	
<b>P25</b> 6E	<b>MAINS FAIL REPORTING DELAY</b> (0-9999 sec)	900 sec	
<b>P25</b> 7E	<b>RECEIVER FAIL DELAY (0-9999 SEC)</b>	0 sec (disable)	
<b>P25</b> 8E	<b>UPLOAD/DOWNLOAD SITE CODE NUMBER</b> (Up to 8 Characters)	None	
<b>P25</b> 9E	<b>TEMPORARY OUTPUT DISABLE</b> (Output 1-8)		
<b>P25</b> 10E	<b>MISCELLANEOUS PANEL OPTIONS</b> <b>Default: 2, 6</b>		
	<b>1</b>	Panel Tamper is 2k2 EOL	
	<b>2</b>	Direct access to program mode for the installer code	✓
	<b>3</b>	Disable Mains Fail Test	
	<b>4</b>	Listen-in to O/P # 1 Low Volume	
	<b>5</b>	Receiver Fail Lockout (no signal or jamming)	
	<b>6</b>	Send output information to keypad bus	✓
	<b>7</b>	Cannot arm if the system battery is low & AC Fail	
	<b>8</b>	Installer Lockout	
<b>P25</b> 11E	<b>INSTALLER OPTIONS</b> <b>Default: None</b>		
	<b>1</b>	Entry to installer mode resets confirmed alarms	
	<b>2</b>	Entry to installer mode resets tamper alarms	
	<b>3</b>	Entry to installer mode resets low battery alarms	
	<b>4</b>	Entry to installer mode resets supervisory alarms	
	<b>5</b>	Cannot arm if missing keypad	
	<b>6</b>	Cannot arm if phone line fail	
	<b>7</b>	Keypad Lockout after 10 faults codes	
	<b>8</b>	User codes must be 4-6 digits long	
<b>P25</b> 12E	<b>USER OPTIONS</b> This Option can <b>ONLY</b> be accessed from Client Mode		
	<b>1</b>	Hide user codes from installer	none

<b>P25 13E</b>	<b>MISCELLANEOUS USER OPTIONS</b> <b>Default: None</b>		
	<b>1</b>	Code Required to View Memory	
	<b>2</b>	Cancel Handover Zone Function in Stay Mode	
	<b>3</b>	Output Control from Keypad is Disabled when Armed	
	<b>4</b>	Keypad Codes are Disabled During Entry Delay	
	<b>5</b>	No Keypad Indications while Armed	
	<b>6</b>	Monitored KP Buss Output Board	
	<b>7</b>	Enable Keypad Tamper	
	<b>8</b>	Limit Events & Dialler to 3 of any one type	
<b>P26</b>	<b>SETTING THE REAL TIME CLOCK</b>		
<b>P26 1E</b>	<b>REAL TIME HOUR/MINUTE</b> (0-2359)		
<b>P26 2E</b>	<b>REAL TIME DAY OF WEEK</b> (1-7) (1=Sunday, 2=Monday and so on)		
<b>P26 3E</b>	<b>REAL TIME DATE/MONTH/YEAR</b> Value <b>DDMMYY</b> (Date/Month/Year) Example 020906 = 2nd Sept 2006		
<b>P26 4E</b>	<b>DAYLIGHT SAVING IS ACTIVE</b> If LED #1 is On, Daylight Saving is currently active. Turn this bit ON if you are in Daylight Saving Time when the panel is installed.		
<b>P27- P29</b>	<b>DAYLIGHT SAVING SETTINGS START SUNDAY</b>		
<b>P27 1E</b>	<b>DAYLIGHT SAVING START SUNDAY</b> (0-5) (0=daylight saving start time disabled)	<b>1</b>	
<b>P27 2E</b>	<b>DAYLIGHT SAVING END SUNDAY</b> (0-5) (0=daylight saving end time disabled)	<b>3</b>	
<b>P28 1E</b>	<b>DAYLIGHT SAVING START MONTH</b> (1-12)	<b>10</b>	
<b>P28 2E</b>	<b>DAYLIGHT SAVING END MONTH</b> (1-12)	<b>3</b>	
<b>P29 1E</b>	<b>DAYLIGHT SAVING START HOUR</b> (0-23)	<b>2</b>	
<b>P29 2E</b>	<b>DAYLIGHT SAVING END HOUR</b> (0-23)	<b>2</b>	

# OUTPUTS

<b>P34E</b> 1-8E	<b>PROGRAMMING OUTPUT OPTIONS A</b>		
	Option A for Outputs 1-8		
	<b>Default = None</b>		
	1	Invert Output	
	2	Flash Output	
	3	Single Pulse to Output	
	4	Lockout Output	
	5	DTMF Remote Control can operate Output	
	6	User Can operate this Output	
7	<Control> button Can Operate Output		
8	Chime Alarms Flash this Output (linked to Pulse Timer)		
<b>P35E</b> 1-8E	<b>PROGRAMMING OUTPUT OPTIONS B</b>		
	<b>Defaults for outputs 1,2 = 7</b>		
	<b>Defaults for outputs 3-8 = none</b>		
	1	Mains Fail to Output (Operates when P25E6E time out)	
	2	Fuse Failure to Output	
	3	Battery Low to output	
	4	Telephone Line Failure to Output	
	5	Zone Radio Supervised Signal Failure	
	6	Sensor-Watch Alarm	
7	System Tamper to Output <b>(only for Outputs 1 &amp; 2)</b>	✓*	
8	Receiver Failure		
<b>P36E</b> 1-8E	<b>PROGRAMMING OUTPUT OPTIONS C</b>		
	<b>Outputs 1,2 = 1</b>		
	<b>Outputs 3-8= None</b>		
	1	Walk Test Pulse to Output <b>(only for Outputs 1 &amp; 2)</b>	✓*
	2	Pulse Output every 5 seconds when Disarmed	
	3	Pulse Output on Kiss-off Following Arming	
	4	Pulse Output on Kiss-off Following a Zone Alarm	
	5	Disable During dial Delay (P25E 3E)	
	6	Spare	
7	Spare		
8	Spare		



<b>P37E</b> 1-8E	<b>PROGRAMMING OUTPUT OPTIONS D</b> <b>Default for outputs 1-8 : None</b>		
	<b>1</b>	Siren Driver to Output (requires a horn speaker, outputs 1&2)	
	<b>2</b>	Output Reset/Chime Timers are in Minutes	
	<b>3</b>	Output muted for 10 seconds on key-press if alarm	
	<b>4</b>	Turn Output OFF during Two Way Voice Mode	
	<b>5</b>	Not used	
	<b>6</b>	Not used	
	<b>7</b>	Not used	
	<b>8</b>	Monitored Output (1&2 only) can tell if siren cable is cut	
<b>P38</b> 1-8E	<b>OUTPUT ON DELAY TIME</b> Enter a value 0-9999 Seconds <b>Default 1-8 = 0 Sec</b>		<b>0</b>
<b>P39E</b> 1-8E	<b>OUTPUT PULSE TIME</b> Enter a value 0-255 for 1/10th Sec increments <b>Default 1-8 = 20 (2Sec)</b>		<b>20</b>
<b>P40E</b> 1-8E	<b>OUTPUT RESET TIME</b> Enter a value 0-9999 Seconds (Default = 600 Sec) (if option 2 at P37E is on the reset time is in minutes) <b>Default for outputs 1,2 : 240</b> <b>Default for outputs 3-8 : 0</b>		
<b>P41E</b> 1-8E	<b>OUTPUT CHIME MODE TIME</b> Enter a value 0-255 for 1/10th Sec increments <b>Default 1-8 = 20 (2Sec)</b>		<b>20</b>
<b>P42E</b> 1-8E	<b>START OF OUTPUT COMMAND CONTROL STATUS MESSAGES</b> Enter a value 0-99 <b>Outputs 1-8 = 0</b>		<b>0</b>
<b>P43E</b> 1-8E	<b>UN-MAP AN OUTPUT</b> Remove ALL defaults from the Output		
<b>P44E</b> 1-8E	<b>ASSIGNING A TIME-ZONE TO AN OUTPUT</b> Time-zones that control output 1-8.   Outputs 1-8 Enter a time-zone 1-8		

# AREAS

<b>P45E</b> 1-2E	<b>AREAS A &amp; B OPTIONS A</b> 1 = Area A and 2 = Area B. <b>Default Area 1&amp;2 = 7,8</b>		
	1	Arm button required before code to set	
	2	Stay button required before code to set stay mode	
	3	Code required to set	
	4	Code required to bypass zones	
	5	Spare	
	6	Send Arm at the end of the Exit Delay	
	7	Can Arm only if All Zones are Sealed (Ready)	✓
	8	Can Arm Stay Mode only if All Zones are Sealed (Ready)	✓
<b>P46E</b> 1-2E	<b>AREAS A &amp; B OPTIONS B</b> 1 = Area A and 2 = Area B <b>Default Area 1&amp;2 = None</b>		
	1	Use near and verified alarm reporting for all zones in this area	
	2	Area will arm at end of time-zone	
	3	Area will disarm at beginning of time-zone	
	4	Assign beeps to access tags	
	5	Spare	
	6	Spare	
	7	Cannot Arm if Zone Unsealed at end of Exit Delay	
	8	Spare	
<b>P47E</b> 1-2E	<b>AREAS A &amp; B ARM INDICATION TO OUTPUT</b> <b>1</b> = Area A and <b>2</b> = Area B Area A & B Arm Indication to Output enter a value of 1-8 for each of the 8 outputs. <b>Default Area 1&amp;2 = Output 3</b>		<b>3</b>
<b>P48E</b> 1-2E	<b>AREAS A &amp; B STAY ARM INDICATION TO OUTPUT</b> <b>1</b> = Area A and <b>2</b> = Area B Area A & B Stay Arm Indication to Output enter a value of 1-8 for each of the 8 outputs. <b>Default Area 1&amp;2 = Output 3</b>		<b>3</b>
<b>P49E</b> 1-2E	<b>AREAS A &amp; B DISARM INDICATION TO OUTPUT</b> <b>1</b> = Area A and <b>2</b> = Area B Area A & B Disarm Indication to Output enter a value of 1-8 for each of the 8 outputs. <b>Default Area 1&amp;2 = none</b>		
<b>P50E</b> 1-2E	<b>AREAS A &amp; B PENDANT/ACC. TAG ARM BEEP TO OUTPUT</b> <b>1</b> = Area A and <b>2</b> = Area B Area A & B Beep to Output enter a value of 1-8 for each of the 8 outputs. Output beeps once when armed <b>Default Area 1&amp;2 = none</b>		

<b>P51E</b> 1-2E	<b>AREAS A &amp; B PENDANT/ACC. TAG STAY ARM BEEP TO OUTPUT</b> <b>1</b> = Area A and <b>2</b> = Area B Area A & B Stay Arm Beep to Output enter a value of 1-8 for each of the 8 outputs. Output beeps once when stay armed <b>Area 1&amp;2 = None</b>		
<b>P52E</b> 1-2E	<b>AREAS A &amp; B PENDANT/ACC TAG DISARM BEEP TO OUTPUT</b> <b>1</b> = Area A and <b>2</b> = Area B Area A & B Disarm Beeps to Output enter a value of 1-8 for each of the 8 outputs. Output beeps twice when disarmed <b>Area 1&amp;2 = None</b>		
<b>P53E</b> 1-2E	<b>AREAS A &amp; B PENDANT STAY/ACC. TAG DISARM BEEP TO OUTPUT</b> <b>1</b> = Area A and <b>2</b> = Area B Area A & B Stay Disarm Beeps to Output enter a value of 1-8 for each of the 8 outputs. Output beeps twice when stay disarmed <b>Area 1&amp;2 = None</b>		
<b>P54E</b> 1-2E	<b>AREAS A &amp; B ARM PULSE TO OUTPUT</b> <b>1</b> = Area A and <b>2</b> = Area B Area A & B Arm Pulse to Output enter a value of 1-8 for each of the 8 outputs. <b>Area 1&amp;2 = None</b>		
<b>P55E</b> 1-2E	<b>AREAS A &amp; B STAY ARM PULSE TO OUTPUT</b> <b>1</b> = Area A and <b>2</b> = Area B Area A & B Stay Arm Pulse to Output enter a value of 1-8 for each of the 8 outputs. <b>Area 1&amp;2 = None</b>		
<b>P56E</b> 1-2E	<b>AREAS A &amp; B DISARM PULSE TO OUTPUT</b> <b>1</b> = Area A and <b>2</b> = Area B Area A & B Disarm Pulse to Output enter a value of 1-8 for each of the 8 outputs. <b>Area 1&amp;2 = None</b>		
<b>P57E</b> 1-2E	<b>AREAS A &amp; B STAY DISARM PULSE TO OUTPUT</b> <b>1</b> = Area A and <b>2</b> = Area B Area A & B Stay Disarm Pulse to Output enter a value of 1-8 for each of the 8 outputs. <b>Area 1&amp;2 = None</b>		
<b>P58E</b> 1-2E	<b>AREAS A &amp; B ARMED MODE EXIT DELAY BEEPS TO KEYPAD</b> <b>1</b> = Area A and <b>2</b> = Area B Area A & B Armed Exit Delay Beeps to Keypad enter a value of 1-8 for each of the 8 outputs. <b>(Default = ALL ON) (1,2,3,4,5,6,7,8)</b>	<b>ALL</b>	
<b>P59E</b> 1-2E	<b>AREAS A &amp; B STAY ARMED MODE EXIT DELAY BEEPS TO KEYPAD</b> <b>1</b> = Area A and <b>2</b> = Area B Area A & B Stay Armed Exit Delay Beeps to Keypad enter a value of 1-8 for each of the 8 outputs. <b>Area 1&amp;2 = None</b>		
<b>P60E</b> 1-2E	<b>AREAS A &amp; B ARMED EXIT DELAY TIME</b> <b>1</b> = AREA A AND <b>2</b> = AREA B Area A & B Exit Delay Time enter a value 0-255 sec. <b>Default Area 1&amp;2 = 60 Sec</b>	<b>60</b>	

<b>P61E</b> 1-2E	<b>AREAS A &amp; B STAY ARMED EXIT DELAY TIME</b> <b>1</b> = Area A and <b>2</b> = Area B Area A & B Stay Exit Delay Time enter a value 0-255 sec. (Default = <b>Default Area 1&amp;2 = 60 Sec</b>	<b>60</b>	
<b>P62E</b> 1-2E	<b>AREAS A &amp; B MONITORING ACCOUNT CODE NUMBER</b> <b>1</b> = Area A and <b>2</b> = Area B Area A & B Account Code number enter a value 0000-FFFF. <b>Default Area 1&amp;2 = 0000</b>		
<b>P63E</b> 1-2E	<b>AREAS A &amp; B REMOTE COMMAND CONTROL CODE NUMBER</b> <b>1</b> = Area A and <b>2</b> = Area B Area A & B Remote Command Control code enter a 1-4 digit code 1-9999. <b>Default Area 1&amp;2 = 0</b>		
<b>P64E</b> 1-2E	<b>AREAS A &amp; B START MSG NUMBER FOR COMMAND CONTROL</b> <b>1</b> = Area A and <b>2</b> = Area B Area A & B Start Message Number for Command Control enter a value 0-99. <b>Default Area 1&amp;2 = 0</b>		
<b>P65E</b> 1-2E	<b>AREAS A &amp; B ARMED MODE EXIT DELAY TO OUTPUT</b> <b>1</b> = Area A and <b>2</b> = Area B Area A & B Armed Exit Delay to Output enter a value 1-8 for Outputs 1-8. <b>Default Area 1&amp;2 = None</b>		
<b>P66E</b> 1-2E	<b>AREAS A &amp; B STAY MODE EXIT DELAY TO OUTPUT</b> <b>1</b> = Area A and <b>2</b> = Area B Area A & B Stay Exit Delay to Output enter a value 1-8 for Outputs 1-8. <b>Default Area 1&amp;2 = None</b>		
<b>P67E</b> 1-2E	<b>AREAS A &amp; B DELINQUENCY DELAY</b> <b>1</b> = Area A and <b>2</b> = Area B Area A & B Delinquency Delay enter a value 0-99 Days where 0 = Off. <b>Default Area 1&amp;2 = 0</b>		
<b>P68E</b> 1-2E	<b>AREAS A &amp; B AUTO ARM/DISARM TIME-ZONES</b> <b>1</b> = Area A and <b>2</b> = Area B Auto Arm/Disarm Time-zones enter a value 1-8 for Time-zones 1-8. <b>Default Area 1&amp;2 = None</b>		

# KEYPADS

<b>P71E</b> 1-2E	<b>KEYPAD AREA ASSIGNMENT</b> <b>1</b> = Area A and <b>2</b> = Area B Keypads Assigned to Areas. <b>Default = 1 only for area A</b> Example, 1 - - - - -			
<b>P72E</b> 1-8E	<b>KEYPAD BUTTON OPTIONS</b> Default Keypads 1 - 8=1 - 8			
	1	<b>CHIME</b> or <b>CONTROL PROGRAM</b> buttons enabled	✓	
	2	<b>BYPASS</b> button enabled	✓	
	3	<b>PANIC</b> button enabled	✓	
	4	Delayed panic on <b>PANIC</b> button	✓	
	5	<1>+<3> or <CONTROL>+<CHIME> Panic Alarm Enabled	✓	
	6	<4>+<6> or <A>+<B> Fire Alarm Enabled	✓	
	7	<7>+<9> or <B>+<CHIME> Medical Alarm Enabled	✓	
	8	Stay Armed Beep to Keypad	✓	
<b>P73E</b> 1-8E	<b>ALARM BEEPS &amp; LED CONTROL TO KEYPAD</b> <b>Keypads 1-8: Options 5, 8 ON.</b>			
	1	Mains Fail Beeps Keypad Buzzer		
	2	Fuse Failure Beeps Keypad Buzzer		
	3	Battery Low Beeps Keypad Buzzer		
	4	Telephone Line Failure Beeps Keypad Buzzer		
	5	System Tamper Alarm Beeps Keypad Buzzer	✓	
	6	Receiver Fail Beeps Keypad Buzzer		
	7	Turn Off Keypad LED's when Armed /after 90 sec if not touched		
	8	Turn Off Keypad & Backlight LED's on Mains Failure	✓	
<b>P74E</b> 1-8E	<b>KEYPAD ARM BUTTON AREA ASSIGNMENT</b> <b>Keypads 1-8: Option 1 ON.</b>			
	1	ARM Button assigned to Area A	✓	
	2	ARM Button assigned to Area B		
<b>P75E</b> 1-8E	<b>KEYPAD ARM BUTTON AREA OPTIONS</b> <b>Keypads 1-8: Options 1, 7 ON.</b>			
	1	ARM Button can Arm	✓	
	2	ARM Button can Stay Mode Arm		
	3	ARM Button can Disarm at All Times		
	4	ARM Button can Disarm Stay Mode at All Times		
	5	ARM Button can Reset Alarms		
	6	ARM Button can Arm Latchkey Mode		
	7	ARM Button can Disarm During Exit Delay	✓	
	8	ARM Button can Disarm Stay Mode During Exit Delay		

<b>P76E</b> 1-8E	<b>KEYPAD STAY BUTTON AREA ASSIGNMENT</b>		
	<b>Keypads 1-8: Option 1 ON.</b>		
	1	STAY Button assigned to Area A	✓
	2	STAY Button assigned to Area B	
<b>P77E</b> 1-8E	<b>KEYPAD STAY BUTTON AREA OPTIONS</b>		
	<b>Keypads 1-8 = 2,8</b>		
	1	ARM Button can Arm	
	2	ARM Button can Stay Mode Arm	✓
	3	ARM Button can Disarm at All Times	
	4	ARM Button can Disarm Stay Mode at All Times	
	5	ARM Button can Reset Alarms	
	6	ARM Button can Arm Latchkey Mode	
	7	ARM Button can Disarm During Exit Delay	
8	ARM Button can Disarm Stay Mode During Exit Delay	✓	
<b>P78E</b> 1-8E	<b>KEYPAD A BUTTON AREA ASSIGNMENT</b>		
	<b>Keypads 1-8 = 1</b>		
	1	A Button assigned to Area A	✓
	2	A Button assigned to Area B	
<b>P79E</b> 1-8E	<b>KEYPAD A BUTTON AREA OPTIONS</b>		
	<b>Keypads 1-8 = 1, 7.</b>		
	1	A Button can Arm	✓
	2	A Button can Stay Mode Arm	
	3	A Button can Disarm at All Times	
	4	A Button can Disarm Stay Mode at All Times	
	5	A Button can Reset Alarms	
	6	A Button can Arm Latchkey Mode	
	7	A Button can Disarm During Exit Delay	✓
8	A Button can Disarm Stay Mode During Exit Delay		
<b>P80E</b> 1-8E	<b>KEYPAD B BUTTON AREA OPTIONS</b>		
	<b>Keypads 1-8 = none</b>		
	1	B Button assigned to Area A	
	2	B Button assigned to Area B	
<b>P81E</b> 1-8E	<b>KEYPAD B BUTTON AREA OPTIONS</b>		
	<b>Keypads 1-8 = 1, 7 (see also next page)</b>		
	1	B Button can Arm	✓
	2	B Button can Stay Mode Arm	
	3	B Button can Disarm at All Times	
	4	B Button can Disarm Stay Mode at All Times	
	5	B Button can Reset Alarms	
6	B Button can Arm Latchkey Mode		

	7	B Button can Disarm During Exit Delay	✓	
	8	B Button can Disarm Stay Mode During Exit Delay		
<b>P82E</b> 1-8E	<b>KEYPAD TO OUTPUT MASK-ACCESS CONTROL</b>			
	<b>Keypads 1-8 = 1-8 ON</b>			
	1	Keypad is linked to Output # 1	✓	
	2	Keypad is linked to Output # 2	✓	
	3	Keypad is linked to Output # 3	✓	
	4	Keypad is linked to Output # 4	✓	
	5	Keypad is linked to Output # 5	✓	
	6	Keypad is linked to Output # 6	✓	
	7	Keypad is linked to Output # 7	✓	
	8	Keypad is linked to Output # 8	✓	
<b>P83E</b> 1-8E	<b>CONTROL BUTTON TO OUTPUT MASK (ACCESS CONTROL)</b>			
	<b>Keypads 1-8 = 1-8 ON</b>			
	1	Keypad Control Button is linked to Output # 1	✓	
	2	Keypad Control Button is linked to Output # 2	✓	
	3	Keypad Control Button is linked to Output # 3	✓	
	4	Keypad Control Button is linked to Output # 4	✓	
	5	Keypad Control Button s linked to Output # 5	✓	
	6	Keypad Control Button is linked to Output # 6	✓	
	7	Keypad Control Button s linked to Output # 7	✓	
	8	Keypad Control Button is linked to Output # 8	✓	
<b>P84E</b> 1-8E	<b>KEYPAD PANIC BUTTON OR 1&amp;3 ALARM TO OUTPUTS</b>			
	<b>Keypads 1-8: Options 1, 2 ON.</b>			
	1	Keypad panic button or 1&3 turns on output # 1	✓	
	2	Keypad panic button or 1&3 turns on output # 2	✓	
	3	Keypad panic button or 1&3 turns on output # 3		
	4	Keypad panic button or 1&3 turns on output # 4		
	5	Keypad panic button or 1&3 turns on output # 5		
	6	Keypad panic button or 1&3 turns on output # 6		
	7	Keypad panic button or 1&3 turns on output # 7		
	8	Keypad panic button or 1&3 turns on output # 8		
<b>P85E</b> 1-8E	<b>FIRE 4&amp;6 ALARM TO OUTPUTS</b>			
	<b>Keypads 1-8 = 1, 2 (see also next page)</b>			
	1	Keypad fire (4&6) alarm turns on Output # 1	✓	
	2	Keypad fire (4&6) alarm turns on Output # 2	✓	
	3	Keypad fire (4&6) alarm turns on Output # 3		
	4	Keypad fire (4&6) alarm turns on Output # 4		
	5	Keypad fire (4&6) alarm turns on Output # 5		
	6	Keypad fire (4&6) alarm turns on Output # 6		

	7	Keypad fire (4&6) alarm turns on Output # 7		
	8	Keypad fire (4&6) alarm turns on Output # 8		
<b>P86E</b> 1-8E	<b>MEDICAL 7&amp;9 ALARM TO OUTPUTS</b>			
	<b>Keypads 1-8 = 1, 2</b>			
	1	Keypad Medical 7&9 Alarm turns on Output # 1	✓	
	2	Keypad Medical 7&9 Alarm turns on Output # 2	✓	
	3	Keypad Medical 7&9 Alarm turns on Output # 3		
	4	Keypad Medical 7&9 Alarm turns on Output # 4		
	5	Keypad Medical 7&9 Alarm turns on Output # 5		
	6	Keypad Medical 7&9 Alarm turns on Output # 6		
	7	Keypad Medical 7&9 Alarm turns on Output # 7		
	8	Keypad Medical 7&9 Alarm turns on Output # 8		
<b>P87E</b> 1-8E	<b>DURESS ALARM TO OUTPUTS</b>			
	<b>Keypads 1-8 = None.</b>			
	1	Keypad Duress Alarm turns on Output # 1		
	2	Keypad Duress Alarm turns on Output # 2		
	3	Keypad Duress Alarm turns on Output # 3		
	4	Keypad Duress Alarm turns on Output # 4		
	5	Keypad Duress Alarm turns on Output # 5		
	6	Keypad Duress Alarm turns on Output # 6		
	7	Keypad Duress Alarm turns on Output # 7		
	8	Keypad Duress Alarm turns on Output # 8		
<b>P88E</b> 1-8E	<b>KEYPAD "TAMPER SWITCH" ALARM TO OUTPUTS</b>			
	<b>Keypads 1-8 = 1,2 ON</b>			
	1	Keypad Tamper Switch Alarm turns on Output # 1	✓	
	2	Keypad Tamper Switch Alarm turns on Output # 2	✓	
	3	Keypad Tamper Switch Alarm turns on Output # 3		
	4	Keypad Tamper Switch Alarm turns on Output # 4		
	5	Keypad Tamper Switch Alarm turns on Output # 5		
	6	Keypad Tamper Switch Alarm turns on Output # 6		
	7	Keypad Tamper Switch Alarm turns on Output # 7		
	8	Keypad Tamper Switch Alarm turns on Output # 8		
<b>P89E</b> 1-8E	<b>KEYPAD WRONG CODE ALARM TO OUTPUTS</b>			
	<b>Keypads 1-8 = None (see also next page)</b>			
	1	Keypad Wrong Code Alarm turns on Output # 1		
	2	Keypad Wrong Code Alarm turns on Output # 2		
	3	Keypad Wrong Code Alarm turns on Output # 3		
	4	Keypad Wrong Code Alarm turns on Output # 4		
	5	Keypad Wrong Code Alarm turns on Output # 5		
	6	Keypad Wrong Code Alarm turns on Output # 6		



	7	Keypad Wrong Code Alarm turns on Output # 7		
	8	Keypad Wrong Code Alarm turns on Output # 8		
<b>P90E</b> 1-8E	<b>MANUALLY OPERATED PANIC ALARM BEEPS TO KEYPADS</b>			
	<b>Keypads 1-8 = 1-8 ON</b>			
	1	A Panic Alarm at the selected keypad Beeps KP # 1	✓	
	2	A Panic Alarm at the selected keypad Beeps KP # 2	✓	
	3	A Panic Alarm at the selected keypad Beeps KP # 3	✓	
	4	A Panic Alarm at the selected keypad Beeps KP # 4	✓	
	5	A Panic Alarm at the selected keypad Beeps KP # 5	✓	
	6	A Panic Alarm at the selected keypad Beeps KP # 6	✓	
	7	A Panic Alarm at the selected keypad Beeps KP # 7	✓	
	8	A Panic Alarm at the selected keypad Beeps KP # 8	✓	
<b>P91E</b> 1-8E	<b>MANUALLY OPERATED FIRE ALARM BEEPS TO KEYPADS</b>			
	<b>Keypads 1-8 = 1-8 ON</b>			
	1	A Fire Alarm at the selected keypad Beeps KP # 1	✓	
	2	A Fire Alarm at the selected keypad Beeps KP # 2	✓	
	3	A Fire Alarm at the selected keypad Beeps KP # 3	✓	
	4	A Fire Alarm at the selected keypad Beeps KP # 4	✓	
	5	A Fire Alarm at the selected keypad Beeps KP # 5	✓	
	6	A Fire Alarm at the selected keypad Beeps KP # 6	✓	
	7	A Fire Alarm at the selected keypad Beeps KP # 7	✓	
	8	A Fire Alarm at the selected keypad Beeps KP # 8	✓	
<b>P92E</b> 1-8E	<b>MANUALLY OPERATED MEDICAL ALARM BEEPS TO KEYPADS</b>			
	<b>Keypads 1-8 = 1-8 ON</b>			
	1	A Medical Alarm at selected keypad Beeps KP # 1	✓	
	2	A Medical Alarm at selected keypad Beeps KP # 2	✓	
	3	A Medical Alarm at selected keypad Beeps KP # 3	✓	
	4	A Medical Alarm at selected keypad Beeps KP # 4	✓	
	5	A Medical Alarm at selected keypad Beeps KP # 5	✓	
	6	A Medical Alarm at selected keypad Beeps KP # 6	✓	
	7	A Medical Alarm at selected keypad Beeps KP # 7	✓	
	8	A Medical Alarm at selected keypad Beeps KP # 8	✓	
<b>P93E</b> 1-8E	<b>WRONG CODE OR KEYPAD TAMPER SWITCH ALARM BEEPS TO KEYPADS</b>			
	<b>Keypads 1-8: None (see also next page)</b>			
	1	A Wrong Code or KP Tamper Alarm at Keypad 1-8 Beeps KP # 1		
	2	A Wrong Code or KP Tamper Alarm at Keypad 1-8 Beeps KP # 2		
	3	A Wrong Code or KP Tamper Alarm at Keypad 1-8 Beeps KP # 3		
	4	A Wrong Code or KP Tamper Alarm at Keypad 1-8 Beeps KP # 4		
	5	A Wrong Code or KP Tamper Alarm at Keypad 1-8 Beeps KP # 5		
	6	A Wrong Code or KP Tamper Alarm at Keypad 1-8 Beeps KP # 6		

	<b>7</b>	A Wrong Code or KP Tamper Alarm at Keypad 1-8 Beeps KP # 7		
	<b>8</b>	A Wrong Code or KP Tamper Alarm at Keypad 1-8 Beeps KP # 8		
<b>P94E</b> 1-8E		Chime Alarm Beep Time at a Keypad The Time the Chime Alarm sounds at Each Keypad enter a value 0-255 1/10th sec. <b>Keypads1-8 = 20 (2 Seconds)</b>	<b>20</b>	
<b>P98E</b> 1-8E		<b>PROXIMITY READER LED TO OUTPUT MAPPING</b> <b>Keypads 1-8 = None.</b>		
	<b>1</b>	Proximity Reader 1-8 LED follows the state of Output # 1		
	<b>2</b>	Proximity Reader 1-8 LED follows the state of Output # 2		
	<b>3</b>	Proximity Reader 1-8 LED follows the state of Output # 3		
	<b>4</b>	Proximity Reader 1-8 LED follows the state of Output # 4		
	<b>5</b>	Proximity Reader 1-8 LED follows the state of Output # 5		
	<b>6</b>	Proximity Reader 1-8 LED follows the state of Output # 6		
	<b>7</b>	Proximity Reader 1-8 LED follows the state of Output # 7		
	<b>8</b>	Proximity Reader 1-8 LED follows the state of Output # 8		
<b>P99E</b> 1-8E		<b>LEARN PROXIMITY READER KEYPAD ADDRESS NUMBER</b> Enter a Keypad Address 1-8		

# KEYSWITCHES

<b>P111E</b> 1-2E	<b>KEY-SWITCH AREA ASSIGNMENT</b> K/S 1 & 2 are assigned to Areas A or B <b>K/S # 1 = 1 Area A</b> <b>K/S # 2 = 2 Area B</b>		
<b>P112E</b> 1-2E	<b>KEY-SWITCH ACCESS &amp; OPERATIONAL OPTIONS</b> K/S 1 & 2 Access & Operational Options 1 = K/S # 1 and 2 = K/S # 2 <b>K/S#1=1,3,8</b> <b>K/S#2= 1,3,8</b>		
	<b>1</b> K/S can Arm Area	<input checked="" type="checkbox"/>	
	<b>2</b> K/S can arm Stay Mode	<input type="checkbox"/>	
	<b>3</b> K/S can Disarm Area	<input checked="" type="checkbox"/>	
	<b>4</b> K/S can disarm Stay Mode	<input type="checkbox"/>	
	<b>5</b> K/S has Security Guard Options	<input type="checkbox"/>	
	<b>6</b> K/S will Arm Latchkey Mode	<input type="checkbox"/>	
	<b>7</b> Key-switch is N/O (If turned off the K/S is N/C)	<input type="checkbox"/>	
	<b>8</b> Key-switch is Momentary (If turned off the K/S is Latched)	<input checked="" type="checkbox"/>	

# ZONES

<b>P121E</b> 1-16E Runner-4 1-8E	<b>PROGRAMMING ZONES TO AREAS</b> Assigning Zones to Areas A or B <b>Default Zones 1-16=1</b>		
	1	Assigned to Area A	✓
	2	Assigned to Area B	
<b>P122E</b> 1-16E Runner-4 1-8E	<b>Programming Zone Options A</b> <b>Default Zone 1-8= 1,6,7</b> <b>Default Zone 9-16 = 6,7</b>		
	1	Zone is Active <b>(only Zones 1-8)</b>	✓
	2	Zone is N/O (Off = N/C)	
	3	Not an Exit Delay Zone	
	4	Keypad Zone	
	5	Zone is a Radio Zone	
	6	Zone is a Stay Mode Zone	✓
	7	Zone can be Manually Bypassed	✓
	8	Zone can be Auto-Bypassed	
<b>P123E</b> 1-16E Runner-4 1-8E	<b>PROGRAMMING ZONE OPTIONS B</b> <b>Default Zone 1,3-16= none</b> <b>Default Zone 2 = 1</b>		
	1	Zone is a Handover Zone ( <b>Default for zone2 only</b> )	✓*
	2	Zone is a Two Trigger Zone	
	3	Zone is a 24 Hour Zone	
	4	Zone is a 24 Hour Auto-reset Zone	
	5	Zone is a 24 Hour Fire Zone	
	6	Spare	
	7	Zone is a Chime Zone	
	8	Zone is a Permanent Chime Zone	
<b>P124E</b> 1-16E Runner-4 1-8E	<b>PROGRAMMING ZONE OPTIONS C</b> <b>Defaults for zones 1,2 = 1,2</b> <b>Defaults for zones 3-16 = 2</b>		
	1	Can Arm if Zone is not Ready <b>(for zones 1&amp;2 only )</b>	✓*
	2	Sends Multiple Reports via Dialler <b>(zones 3 – 16)</b>	✓*
	3	Sensor-Watch Zone	
	4	Zone is on Soak Test	
	5	Zone will report to Area B Account Number	
	6	Zone will Not Report 24 hour Alarms via Dialler	
	7	Pulse Output on Kiss-off Following a Zone Alarm	
	8	Exit Terminator Zone	

<b>P125E</b> 1-8E  Runner-4 1-4E	<b>PROGRAMMING ZONE EOL (END-OF-LINE) OPTIONS</b> <b>Default Zones1-8=0</b>			
	<b>0</b>	<b>Short circuit</b>	✓	
	<b>1</b>	Terminated with a 1K resistor		
	<b>2</b>	Terminated with a 1K5 resistor		
	<b>3</b>	Terminated with a 2K2 resistor		
	<b>4</b>	Terminated with a 3K3 resistor		
	<b>5</b>	Terminated with a 3K9 resistor		
	<b>6</b>	Terminated with a 4K7 resistor		
	<b>7</b>	Terminated with a 5K6 resistor		
	<b>8</b>	Terminated with a 6K8 resistor		
	<b>9</b>	Terminated with a 10K resistor		
	<b>10</b>	Terminated with a 12K resistor		
	<b>11</b>	Terminated with a 22K resistor		
	<b>12</b>	Terminated with a 2K2/4K7 resistor		
	<b>13</b>	Terminated with a 3K3/6K8 resistor		
	<b>14</b>	Terminated with a 2K2/4K7/8K2 resistor		
<b>15</b>	Terminated with a 4K7/8K2 resistor			
<b>P126E</b> 1-8E  Runner-4 1-4E	<b>PROGRAMMING ZONE RESPONSE</b> <b>1 to 8 Vibration mode</b> (Default = 9) For using the vibration mode Zone EOL-P125E, MUST be type 3 only) 1 = highest and 8 is lowest sensitivity level. <b>9 to 26 Normal zone mode</b> Response time = approx 200ms -1sec <b>Default Zones1-8=9</b>		<b>9</b>	
<b>P127E</b> 1-16E  Runner-4 1-8E	<b>PROGRAMMING THE RADIO ZONE TYPE FROM THE LIST</b> Enter a value 1-35 <b>Default Zones1-16=3</b>			
	<b>0</b>	Not In Use		
	<b>1</b>	Not In Use		
	<b>2</b>	Not In Use		
	<b>3</b>	CROW Freewave with checksum (supervised signal active)	✓	
	<b>4</b>	CROW Freewave with checksum (supervised Non-active)		
	<b>5</b>	Not In Use		
	<b>6</b>	Not In Use		
	<b>11</b>	Not In Use		
	<b>12</b>	Not In Use		
	<b>31</b>	Not In Use		
	<b>32</b>	Not In Use		
	<b>33</b>	Not In Use		
	<b>34</b>	Not In Use		

	35	Not In Use		
<b>P128E</b> 1-16E	<b>ARMED ZONE ALARMS TO OUTPUTS</b>			
Runner-4 1-8E	<b>Default Zones1-16=1, 2</b>			
	1	Zone Alarm Turns On Output # 1	✓	
	2	Zone Alarm Turns On Output # 2	✓	
	3	Zone Alarm Turns On Output # 3		
	4	Zone Alarm Turns On Output # 4		
	5	Zone Alarm Turns On Output # 5		
	6	Zone Alarm Turns On Output # 6		
	7	Zone Alarm Turns On Output # 7		
	8	Zone Alarm Turns On Output # 8		
<b>P129E</b> 1-16E	<b>STAY ARMED ZONE ALARMS TO OUTPUTS</b>			
Runner-4 1-8E	<b>Default Zones1-16=1, 2</b>			
	1	Stay Mode Zone Alarm Turns On Output # 1	✓	
	2	Stay Mode Zone Alarm Turns On Output # 2	✓	
	3	Stay Mode Zone Alarm Turns On Output # 3		
	4	Stay Mode Zone Alarm Turns On Output # 4		
	5	Stay Mode Zone Alarm Turns On Output # 5		
	6	Stay Mode Zone Alarm Turns On Output # 6		
	7	Stay Mode Zone Alarm Turns On Output # 7		
<b>P130E</b> 1-16E	<b>24 HOUR ZONE ALARMS TO OUTPUTS</b>			
Runner-4 1-8E	<b>Default Zones1-16=1, 2</b>			
	1	24 Hour Zone Alarm Turns On Output # 1	✓	
	2	24 Hour Zone Alarm Turns On Output # 1	✓	
	3	24 Hour Zone Alarm Turns On Output # 3		
	4	24 Hour Zone Alarm Turns On Output # 41		
	5	24 Hour Zone Alarm Turns On Output # 5		
	6	24 Hour Zone Alarm Turns On Output # 6		
	7	24 Hour Zone Alarm Turns On Output # 7		
	8	24 Hour Zone Alarm Turns On Output # 8		
<b>P131E</b> 1-16E	<b>CHIME ZONE ALARMS TO OUTPUTS</b>			
Runner-4 1-8E	<b>Default Zones1-16=None.</b>			
	1	Chime Zone Alarm Turns On Output # 1		
	2	Chime Zone Alarm Turns On Output # 2		
	3	Chime Zone Alarm Turns On Output # 3		
	4	Chime Zone Alarm Turns On Output # 4		
	5	Chime Zone Alarm Turns On Output # 5		
	6	Chime Zone Alarm Turns On Output # 6		
	7	Chime Zone Alarm Turns On Output # 7		
	8	Chime Zone Alarm Turns On Output # 8		

<b>P132E</b> 1-16E  Runner-4 1-8E	<b>ZONE TAMPER ALARMS TO OUTPUTS</b> <b>Default Zones1-16=1, 2</b>		
	1	Zone Tamper Alarm will Turn On Output # 1	✓
	2	Zone Tamper Alarm will Turn On Output # 2	✓
	3	Zone Tamper Alarm will Turn On Output # 3	
	4	Zone Tamper Alarm will Turn On Output # 4	
	5	Zone Tamper Alarm will Turn On Output # 5	
	6	Zone Tamper Alarm will Turn On Output # 6	
	7	Zone Tamper Alarm will Turn On Output # 7	
	8	Zone Tamper Alarm will Turn On Output # 8	
<b>P134E</b> 1-16E  Runner-4 1-8E	<b>ARMED ZONE ALARM BEEPS TO KEYPADS</b> <b>Default Zones1-16=1-8</b>		
	1	Armed Zone Alarm Beeps Keypad #1	✓
	2	Armed Zone Alarm Beeps Keypad #2	✓
	3	Armed Zone Alarm Beeps Keypad #3	✓
	4	Armed Zone Alarm Beeps Keypad #4	✓
	5	Armed Zone Alarm Beeps Keypad #5	✓
	6	Armed Zone Alarm Beeps Keypad #6	✓
	7	Armed Zone Alarm Beeps Keypad #7	✓
	8	Armed Zone Alarm Beeps Keypad #8	✓
<b>P135E</b> 1-16E  Runner-4 1-8E	<b>STAY MODE ZONE ALARM BEEPS TO KEYPADS</b> <b>Default Zones1-16=1-8</b>		
	1	Stay Mode Zone Alarm Beeps Keypad #1	✓
	2	Stay Mode Zone Alarm Beeps Keypad #2	✓
	3	Stay Mode Zone Alarm Beeps Keypad #3	✓
	4	Stay Mode Zone Alarm Beeps Keypad #4	✓
	5	Stay Mode Zone Alarm Beeps Keypad #5	✓
	6	Stay Mode Zone Alarm Beeps Keypad #6	✓
	7	Stay Mode Zone Alarm Beeps Keypad #7	✓
	8	Stay Mode Zone Alarm Beeps Keypad #8	✓
<b>P136E</b> 1-16E  Runner-4 1-8E	<b>24 HOUR ZONE ALARM BEEPS TO KEYPADS</b> <b>Default Zones1-16=1-8</b>		
	1	24 Hour Zone Alarm Beeps Keypad #1	✓
	2	24 Hour Zone Alarm Beeps Keypad #2	✓
	3	24 Hour Zone Alarm Beeps Keypad #3	✓
	4	24 Hour Zone Alarm Beeps Keypad #4	✓
	5	24 Hour Zone Alarm Beeps Keypad #5	✓
	6	24 Hour Zone Alarm Beeps Keypad #6	✓
	7	24 Hour Zone Alarm Beeps Keypad #7	✓
	8	24 Hour Zone Alarm Beeps Keypad #8	✓

<b>P137E</b> 1-16E  Runner-4 1-8E	<b>CHIME ZONE ALARM BEEPS TO KEYPADS</b>		
	<b>Default Zones1-16=1-8</b>		
	1	Chime Zone Alarm Beeps Keypad #1	✓
	2	Chime Zone Alarm Beeps Keypad #2	✓
	3	Chime Zone Alarm Beeps Keypad #3	✓
	4	Chime Zone Alarm Beeps Keypad #4	✓
	5	Chime Zone Alarm Beeps Keypad #5	✓
	6	Chime Zone Alarm Beeps Keypad #6	✓
	7	Chime Zone Alarm Beeps Keypad #7	✓
8	Chime Zone Alarm Beeps Keypad #8	✓	
<b>P139E</b> 1-16E  Runner-4 1-8E	<b>ZONE TAMPER ALARM BEEPS TO KEYPADS</b>		
	<b>Default Zones1-16=1-8</b>		
	0	Not used	
	1	Zone Tamper Alarm Beeps Keypad #1	✓
	2	Zone Tamper Alarm Beeps Keypad #2	✓
	3	Zone Tamper Alarm Beeps Keypad #3	✓
	4	Zone Tamper Alarm Beeps Keypad #4	✓
	5	Zone Tamper Alarm Beeps Keypad #5	✓
	6	Zone Tamper Alarm Beeps Keypad #6	✓
7	Zone Tamper Alarm Beeps Keypad #7	✓	
8	Zone Tamper Alarm Beeps Keypad #8	✓	
<b>P140E</b> 1-16E  Runner-4 1-8E	<b>RADIO SUPERVISE ALARM BEEPS TO KEYPADS</b>		
	<b>Default Zones1-16=1-8</b>		
	1	Radio Supervise Alarm Beeps Keypad #1	✓
	2	Radio Supervise Alarm Beeps Keypad #1	✓
	3	Radio Supervise Alarm Beeps Keypad #3	✓
	4	Radio Supervise Alarm Beeps Keypad #4	✓
	5	Radio Supervise Alarm Beeps Keypad #5	✓
	6	Radio Supervise Alarm Beeps Keypad #6	✓
	7	Radio Supervise Alarm Beeps Keypad #7	✓
8	Radio Supervise Alarm Beeps Keypad #8	✓	



<b>P141E</b> 1-16E  Runner-4 1-8E	<b>ZONE SENSOR-WATCH ALARM BEEPS TO KEYPADS</b> <b>Default Zones1-16=1-8</b>		
	1	Zone Sensor-watch Alarm Beeps Keypad #1	✓
	2	Zone Sensor-watch Alarm Beeps Keypad #2	✓
	3	Zone Sensor-watch Alarm Beeps Keypad #3	✓
	4	Zone Sensor-watch Alarm Beeps Keypad #4	✓
	5	Zone Sensor-watch Alarm Beeps Keypad #5	✓
	6	Zone Sensor-watch Alarm Beeps Keypad #6	✓
	7	Zone Sensor-watch Alarm Beeps Keypad #7	✓
	8	Zone Sensor-watch Alarm Beeps Keypad #8	✓
<b>P142E</b> 1-16E  Runner-4 1-8E	<b>ARMED ZONE ENTRY DELAY BEEPS TO KEYPADS</b> <b>Default Zones1-16=1-8</b>		
	1	Armed Zone Entry Delay Beeps Keypad #1	✓
	2	Armed Zone Entry Delay Beeps Keypad #2	✓
	3	Armed Zone Entry Delay Beeps Keypad #3	✓
	4	Armed Zone Entry Delay Beeps Keypad #4	✓
	5	Armed Zone Entry Delay Beeps Keypad #5	✓
	6	Armed Zone Entry Delay Beeps Keypad #6	✓
	7	Armed Zone Entry Delay Beeps Keypad #7	✓
	8	Armed Zone Entry Delay Beeps Keypad #8	✓
<b>P143E</b> 1-16E  Runner-4 1-8E	<b>STAY MODE ENTRY DELAY BEEPS TO KEYPADS</b> <b>Default Zones1-16=None</b>		
	1	Stay Mode Entry Delay Beeps Keypad #1	
	2	Stay Mode Entry Delay Beeps Keypad #2	
	3	Stay Mode Entry Delay Beeps Keypad #3	
	4	Stay Mode Entry Delay Beeps Keypad #4	
	5	Stay Mode Entry Delay Beeps Keypad #5	
	6	Stay Mode Entry Delay Beeps Keypad #6	
	7	Stay Mode Entry Delay Beeps Keypad #7	
	8	Stay Mode Entry Delay Beeps Keypad #8	
<b>P144E</b> 1-16E  Runner-4 1-8E	<b>ARMED ZONE ENTRY DELAY TIMES</b> Enter a value 0-9999 seconds. <b>Default for zone 1 : 20 sec</b> <b>Default for zone 2 : 20 sec</b> <b>Default for zones 3-16 : 0 sec</b>		
<b>P145E</b> 1-16E  Runner-4 1-8E	<b>STAY MODE ENTRY DELAY TIMES</b> Enter a value 0-9999 seconds. <b>Default for zone 1 : 20 sec</b> <b>Default for zone 2 : 20 sec</b> <b>Default for zones 3-16 : 0 sec</b>		

<b>P146E</b> 1-16E Runner-4 1-8E	<b>ZONE RE-TRIGGER COUNT</b> Enter a value of 0-15 Triggers. <b>Default = 0 Triggers</b>		
<b>P147E</b> 1-16E Runner-4 1-8E	<b>ZONE ALARM 4+2 REPORTING CODE</b> Enter a two digit value 00-FF		
<b>P148E</b> 1-16E Runner-4 1-8E	<b>ZONE ALARM RESTORE 4+2 CODE</b> Enter a two digit value 00-FF		
<b>P149E</b> 1-16E Runner-4 1-8E	<b>ZONE NEAR ALARM 4+2 REPORTING CODE</b> Enter a two digit value 00-FF		
<b>P150E</b> 1-16E Runner-4 1-8E	<b>ZONE NEAR ALARM RESTORE 4+2 CODE</b> Enter a two digit value 00-FF		
<b>P151E</b> 1-16E Runner-4 1-8E	<b>ZONE NEAR ALARM RESTORE 4+2 CODE</b> Enter a two digit value 00-FF		
<b>P152E</b> 1-16E Runner-4 1-8E	<b>ZONE INTRUSION VERIFIED ALARM RESTORE 4+2 CODE</b> Enter a two digit value 00-FF		
<b>P155E</b> 1-16E Runner-4 1-8E	<b>ZONE BYPASS ALARM 4+2 REPORTING CODE</b> Enter a two digit value 00-FF		
<b>P156E</b> 1-16E Runner-4 1-8E	<b>ZONE BYPASS RESTORE 4+2 CODE</b> Enter a two digit value 00-FF		
<b>P157E</b> 1-16E Runner-4 1-8E	<b>ZONE ALARM CONTACT ID REPORTING CODE</b> (Default = 130)		
<b>P158E</b> 1-16E Runner-4 1-8E	<b>ZONE NEAR ALARM CONTACT ID REPORTING CODE</b> (Default = 138)		
<b>P159E</b> 1-16E Runner-4 1-8E	<b>ZONE INTRUSION VERIFIED ALARM CONTACT ID REPORTING CODE</b> (Default = 139)		

<b>P160E</b> 1-16E Runner-4 1-8E	<b>ZONE ALARM VOICE MESSAGE NUMBER</b> Enter a value 0-99 (Default = 1)																																		
<b>P161E</b> 1-16E Runner-4 1-8E	<b>AWAY ZONE ENTRY DELAY TO OUTPUTS</b> <b>Default Zones1-16=None</b> <table border="1" data-bbox="411 421 1203 801"> <tr><td>1</td><td>Armed Zone Entry Delay to output #1</td><td></td><td></td></tr> <tr><td>2</td><td>Armed Zone Entry Delay to output #2</td><td></td><td></td></tr> <tr><td>3</td><td>Armed Zone Entry Delay to output #3</td><td></td><td></td></tr> <tr><td>4</td><td>Armed Zone Entry Delay to output #4</td><td></td><td></td></tr> <tr><td>5</td><td>Armed Zone Entry Delay to output #5</td><td></td><td></td></tr> <tr><td>6</td><td>Armed Zone Entry Delay to output #6</td><td></td><td></td></tr> <tr><td>7</td><td>Armed Zone Entry Delay to output #7</td><td></td><td></td></tr> <tr><td>8</td><td>Armed Zone Entry Delay to output #8</td><td></td><td></td></tr> </table>	1	Armed Zone Entry Delay to output #1			2	Armed Zone Entry Delay to output #2			3	Armed Zone Entry Delay to output #3			4	Armed Zone Entry Delay to output #4			5	Armed Zone Entry Delay to output #5			6	Armed Zone Entry Delay to output #6			7	Armed Zone Entry Delay to output #7			8	Armed Zone Entry Delay to output #8				
1	Armed Zone Entry Delay to output #1																																		
2	Armed Zone Entry Delay to output #2																																		
3	Armed Zone Entry Delay to output #3																																		
4	Armed Zone Entry Delay to output #4																																		
5	Armed Zone Entry Delay to output #5																																		
6	Armed Zone Entry Delay to output #6																																		
7	Armed Zone Entry Delay to output #7																																		
8	Armed Zone Entry Delay to output #8																																		
<b>P162E</b> 1-16E Runner-4 1-8E	<b>STAY MODE ENTRY DELAY TO OUTPUTS</b> <b>Default Zones1-16=None</b> <table border="1" data-bbox="411 884 1203 1265"> <tr><td>1</td><td>Stay Mode Entry Delay to output #1</td><td></td><td></td></tr> <tr><td>2</td><td>Stay Mode Entry Delay to output #2</td><td></td><td></td></tr> <tr><td>3</td><td>Stay Mode Entry Delay to output #3</td><td></td><td></td></tr> <tr><td>4</td><td>Stay Mode Entry Delay to output #4</td><td></td><td></td></tr> <tr><td>5</td><td>Stay Mode Entry Delay to output #5</td><td></td><td></td></tr> <tr><td>6</td><td>Stay Mode Entry Delay to output #6</td><td></td><td></td></tr> <tr><td>7</td><td>Stay Mode Entry Delay to output #7</td><td></td><td></td></tr> <tr><td>8</td><td>Stay Mode Entry Delay to output #8</td><td></td><td></td></tr> </table>	1	Stay Mode Entry Delay to output #1			2	Stay Mode Entry Delay to output #2			3	Stay Mode Entry Delay to output #3			4	Stay Mode Entry Delay to output #4			5	Stay Mode Entry Delay to output #5			6	Stay Mode Entry Delay to output #6			7	Stay Mode Entry Delay to output #7			8	Stay Mode Entry Delay to output #8				
1	Stay Mode Entry Delay to output #1																																		
2	Stay Mode Entry Delay to output #2																																		
3	Stay Mode Entry Delay to output #3																																		
4	Stay Mode Entry Delay to output #4																																		
5	Stay Mode Entry Delay to output #5																																		
6	Stay Mode Entry Delay to output #6																																		
7	Stay Mode Entry Delay to output #7																																		
8	Stay Mode Entry Delay to output #8																																		
<b>P163E</b> 1-16E Runner-4 1-8E	<b>SENSOR-WATCH TIMER</b> Enter a value 0-9999 Minutes <b>Default Zones 1-16= 7200 minutes [120 Hours]</b>	<b>7200</b>																																	
<b>P164E</b> 1-16E Runner-4 1-8E	<b>ENROLLING (LEARN) RADIO ZONE CODES</b>																																		
<b>P165E</b> 1-16E Runner-4 1-8E	<b>DELETE A SPECIFIC RADIO ZONE CODE</b>																																		
<b>P166E</b> 1-16E Runner-4 1-8E	<b>FIND RADIO ZONE MEMORY LOCATION</b> Finds the zone number of any Radio Zone code stored in the panel. When using the LED Keypad press the <b>OE</b> keys in sequence.																																		

<b>P167E 1-16E</b>	<b>ZONE NEAR ALARM to OUTPUT</b> <b>Default Zones1-16=None</b>		
Runner-4 1-8E	<b>1</b>	Zone near alarm to output 1	
	<b>2</b>	Zone near alarm to Output 2	
	<b>3</b>	Zone near alarm to Output 3	
	<b>4</b>	Zone near alarm to Output 4	
	<b>5</b>	Zone near alarm to Output 5	
	<b>6</b>	Zone near alarm to Output 6	
	<b>7</b>	Zone near alarm to Output 7	
	<b>8</b>	Zone near alarm to Output 8	
<b>P168E 1-16E</b>	<b>ZONE CONFIRMED ALARM to OUTPUT</b> <b>Default Zones1-16=None</b>		
Runner-4 1-8E	<b>1</b>	Zone confirmed alarm to output 1	
	<b>2</b>	Zone confirmed alarm to Output 2	
	<b>3</b>	Zone confirmed alarm to Output 3	
	<b>4</b>	Zone confirmed alarm to Output 4	
	<b>5</b>	Zone confirmed alarm to Output 5	
	<b>6</b>	Zone confirmed alarm to Output 6	
	<b>7</b>	Zone confirmed alarm to Output 7	
	<b>8</b>	Zone confirmed alarm to Output 8	

# TIME ZONES

<b>P170E</b> 1-8E	<b>PROGRAMMING HOLIDAYS</b> Holidays 1-8 Days enter the values as <b>DDMMYY</b>		
<b>P171E</b> 1-8E	<b>PROGRAMMING TIME ZONE DAYS</b> Time Zones 1-8 Days <b>Default = All Off</b>		
	1	Sunday	
	2	Monday	
	3	Tuesday	
	4	Wednesday	
	5	Thursday	
	6	Friday	
	7	Saturday	
	8	Invert	
<b>P172E</b> 1-8E	<b>TIME ZONES 1-8 START TIME</b> Enter a value 0000-2359 <b>Default = 0000</b>		
<b>P173E</b> 1-8E	<b>TIME ZONES 1-8 END TIME</b> Enter a value 0000-2359 (Default = 0000)		
<b>P174E</b> 1-8E	<b>TIME ZONE 1-8 OPTIONS</b> <b>Zones 1-8 = None</b>		
	1	Ignore Holidays	
	2	Spare	

# DIALLER

<b>P175E</b> 1E	<b>DIALLER PROGRAMMING OPTIONS 1</b> <b>Default = 1,2,7</b>		
	0	Not used	
	1	Dialler is Enabled	✓
	2	Fax Defeat	✓
	3	Disable Telephone Line Monitoring	
	4	DTMF or Pulse Dial (For DTMF 4&5 must be both OFF)	
	5	DTMF or Reverse Pulse Dial (For DTMF, 4&5 must be both OFF)	
	6	Send long DTMF tones during dialling	
	7	Auto Detect Modem Mode	✓
8	Force V21 Mode		
<b>P175E</b> 2E	<b>DIALLER PROGRAMMING OPTIONS 2</b> <b>Default = 1</b>		
	1	Step number on each call	✓
	2	Upload/Download use callback	
	3	Upload/Download only if disarmed	
	4	Test calls only if armed	
	5	Test Time Period is in days	
	6	Hold line open following Domestic/Voice report for DTMF control	
	7	First to Open Last to Close Reporting	
8	Alarm Enables Answer (2 way Voice)		
<b>P175E</b> 3E	<b>AUTO-ANSWER RING COUNT</b> Enter a value 0-99 <b>Default = 8</b>		<b>8</b>
<b>P175E</b> 4E	<b>TIME TO THE FIRST DIALLER TEST CALL</b> Enter a value 0-2359 (Default = 2300)		<b>2300</b>
<b>P175E</b> 5E	<b>TEST CALL TIME PERIOD</b> Enter a value 0-255 hours 0 = No test <b>Default = 24</b>		<b>24</b>
<b>P175E</b> 6E	<b>KEYPAD LISTEN-IN OPTIONS</b> <b>Default = 1-7</b>		
	1	Enabled During Dialling in Disarm State only	✓
	2	Enabled During Dialling in Armed State only	✓
	3	Enabled During Dialling in Stay Mode State only	✓
	4	Enabled Throughout the call in Disarm State only	✓
	5	Enabled Throughout the call in Armed State only	✓
	6	Enabled Throughout the call in Stay Mode State only	✓
	7	Listen-in Enabled when the panel answers a call	✓
8	Enabled at All Times		

<b>P175E</b> 7E	<b>OUTPUT # 1 LISTEN-IN OPTIONS</b>		
	<b>Default = None</b>		
	<b>1</b>	Enabled During Dialling in Disarm State only	
	<b>2</b>	Enabled During Dialling in Armed State only	
	<b>3</b>	Enabled During Dialling in Stay Mode State only	
	<b>4</b>	Enabled Throughout the call in Disarm State only	
	<b>5</b>	Enabled Throughout the call in Armed State only	
	<b>6</b>	Enabled Throughout the call in Stay Mode State only	
	<b>7</b>	Listen-in Enabled when the panel answers a call	
<b>8</b>	Enabled at All Times		
<b>P175E</b> 8E	<b>DIALLING PRE-FIX NUMBER</b> Enter a value 1-16 digits <b>Default = None</b>		
<b>P175E</b> 9E	<b>PANIC ALARM CONTACT ID REPORTING CODE</b> <b>Default = 120</b>	<b>120</b>	
<b>P175E</b> 10E	<b>FIRE ALARM CONTACT ID REPORTING CODE</b> <b>Default = 110</b>	<b>110</b>	
<b>P175E</b> 11E	<b>MEDICAL ALARM CONTACT ID REPORTING CODE</b> Enter a value 1-4 digit code (1-9999) <b>Default = 100</b>	<b>100</b>	
<b>P175E</b> 12E	<b>OUTPUT COMMAND CONTROL CODE NUMBER</b> Enter a value 1-4 digit code (1-9999) (Default = 0)	<b>0</b>	
<b>P175E</b> 13E	<b>MICROPHONE ON/OFF CMD CONTROL CODE NUMBER</b> Enter a value 1-4 digit code (1-9999) (Default = 0)	<b>0</b>	
<b>P175E</b> 14E	<b>DIALLER ACKNOWLEDGE CODE</b> Voice/Domestic Acknowledge Code Enter a value 1-4 digit code (1-9999) (Default = 0)	<b>0</b>	
<b>P175E</b> 15E	<b>FORCE TEST CALL CODE</b> Enter a value 1-4 digit code (1-9999) (Default = 0 disables the feature)	<b>0</b>	
<b>P176</b> 1E-11E	<b>PROGRAMMING VOICE BOARD MESSAGES</b>		
<b>P176E</b> 1E	<b>KEYPAD OR RADIO PANIC ALARM VOICE MESSAGE NUMBER</b> Enter a value 0-99	<b>1</b>	
<b>P176E</b> 2E	<b>FIRE ALARM VOICE MESSAGE NUMBER</b> Enter a value 0-99	<b>1</b>	
<b>P176E</b> 3E	<b>MEDICAL ALARM VOICE MESSAGE NUMBER</b> Enter a value 0-99	<b>1</b>	
<b>P176E</b> 4E	<b>MAINS FAILURE VOICE MESSAGE NUMBER</b> Enter a value 0-99	<b>1</b>	
<b>P176E</b> 5E	<b>MAINS RESTORE VOICE MESSAGE NUMBER</b> Enter a value 0-99	<b>1</b>	
<b>P176E</b> 6E	<b>BATTERY LOW VOICE MESSAGE NUMBER</b> Enter a value 0-99	<b>1</b>	
<b>P176E</b> 7E	<b>BATTERY RESTORED VOICE MESSAGE NUMBER</b> Enter a value 0-99	<b>1</b>	

<b>P176E</b> 8E	<b>TAMPER (ZONE/RADIO/SYSTEM) VOICE MESSAGE NUMBER</b> Enter a value 0-99	<b>1</b>	
<b>P176E</b> 9E	<b>DURESS ALARM VOICE MESSAGE NUMBER</b> Enter a value 0-99	<b>1</b>	
<b>P176E</b> 10E	<b>LATCHKEY DISARM VOICE MESSAGE NUMBER</b> Enter a value 0-99	<b>1</b>	
<b>P176E</b> 11E	<b>MANUAL TEST INITIATED VOICE MESSAGE</b> Enter a value 0-99	<b>1</b>	



# TELEPHONE NUMBERS

<b>P181E</b> 1-8E	<b>PROGRAMMING TELEPHONE NUMBER</b> Enter a value 1-16 digit code (Default = 0)	<b>0</b>	
<b>P182E</b> 1-8E	<b>TELEPHONE NUMBER REPORTING FORMATS</b> <b>Telephone No 1,2 = 1</b> <b>Telephone No 3-8 = 2</b>		
	<b>1</b> Contact ID <b>(Only for Phone 1 &amp; 2)</b>	✓*	
	<b>2</b> Domestic Dial	✓	
	<b>3</b> Pager		
	<b>4</b> Speech Dialler		
	<b>5</b> 4+2 10pps (Handshake 1400/ Tone 1900)		
	<b>6</b> 4+2 10pps (Handshake 2300/ Tone 1800)		
	<b>7</b> 4+2 20pps (Handshake 1400/ Tone 1900)		
	<b>8</b> 4+2 20pps (Handshake 2300/ Tone 1800)		
	<b>9</b> 4+2 DTMF (with Checksum)		
	<b>10</b> SIA		
	<b>11</b> SIA Slow		
<b>P183E</b> 1-8E	<b>TELEPHONE NUMBER REPORTING OPTIONS</b> <b>Telephone No 1-8 = 2 ,6</b>		
	<b>1</b> Stop Dialling if Kissed off		
	<b>2</b> Monitor Call Progress	✓	
	<b>3</b> Blind Dial		
	<b>4</b> Use Group Numbers for Contact ID Reporting		
	<b>5</b> Stay On-line after Alarm report for two way voice		
	<b>6</b> Auto Kiss-off for Voice/Domestic Reporting	✓	
	<b>7</b> Use the Dialling Pre-fix		
	<b>8</b> Is to be used as the "Call-back" Number (Only For Telephone No 8)		
<b>P184E</b> 1-8E	<b>MAXIMUM DIAL ATTEMPTS PER TELEPHONE NUMBER</b> Enter a value 0-99 <b>Telephone 1-8 = 3.</b>	<b>3</b>	
<b>P186E</b> 1-8E	<b>DIALLER REPORTING OPTIONS A</b> <b>Telephone No 1-8 = 1-8</b>		
	<b>1</b> Report Mains Failure	✓	
	<b>2</b> Report Battery Low	✓	
	<b>3</b> Report Radio Battery Low	✓	
	<b>4</b> Report Line Fail	✓	
	<b>5</b> Report System Tamper	✓	
	<b>6</b> Report Keypad Tamper	✓	
	<b>7</b> Report Zone Tamper	✓	

	8	Report Radio Zone Tamper	✓	
<b>P187E</b> 1-8E	<b>DIALLER REPORTING OPTIONS B</b>			
	<b>Telephone No 1-8 = 1-8.</b>			
	1	Report Duress Alarm	✓	
	2	Report Supervised Radio Alarm	✓	
	3	Report Zone Sensor-watch Alarm	✓	
	4	Report Manual Panic Alarm	✓	
	5	Report Manual Fire Alarm	✓	
	6	Report Manual Medical Alarm	✓	
	7	Report Radio Pendant Panic Alarm	✓	
8	Report Zone Bypasses	✓		
<b>P188E</b> 1-8E	<b>DIALLER REPORTING OPTIONS C</b>			
	<b>Telephone No 1-8 = 1, 2,5,7,8.</b>			
	1	Report Arm/Disarm	✓	
	2	Report Stay Mode Arm/Disarm	✓	
	3	Report Disarm only after an Activation		
	4	Report Stay Mode Disarm only after an Activation		
	5	Report Stay Mode Zone Alarms	✓	
	6	Report Access to Program Mode		
	7	Report 24 Hour Alarms if Domestic/Voice mode set	✓	
8	Report Zone Restores	✓		
<b>P189E</b> 1-8E	<b>DIALLER REPORTING OPTIONS D</b>			
	<b>Telephone No 1-8 = 3,4,5,7</b>			
	1	Report Latchkey Disarm		
	2	Report Delinquent		
	3	Report Tests	✓	
	4	Report Fuse Failure	✓	
	5	Report Output 1 or 2 Fail	✓	
	6	Report RTC (Real Time Clock) Time changed		
	7	Report Keypad Buss Trouble	✓	
8	Report RF Interference (Jamming) Detected			
<b>P192E</b> 1-8E	<b>DIVERT AREA EVENTS</b>			
	<b>(1 = Area A and 2 = Area B)</b>			
	1	Dial on away arm		
	2	Dial on away disarm		
	3	Dial on stay arm		
	4	Dial on stay disarm		
	5	Dial if Key-switch activation		
	6	Dial if Time zone activation		
7	Dial if DTMF or PC activation			

	<b>8</b>	Dial if keypad ARM or STAY single button activation		
<b>P193E</b> 1-8E	<b>DIVERT NUMBER OPTIONS</b> ( <b>1</b> = Divert on and <b>2</b> = Divert off)= None			
	<b>1</b>	Spare		
	<b>2</b>	Spare		
	<b>3</b>	Blind Dial		
	<b>4</b>	Spare		
	<b>5</b>	Spare		
	<b>6</b>	Spare		
	<b>7</b>	Use the Dialling Pre-fix		
	<b>8</b>	Spare		
<b>P194E</b> 1-8E	<b>DIVERT NUMBERS</b> ( <b>1</b> = Divert on and <b>2</b> = Divert off) Enter a value 1-16 digits			
	<b>1</b>	Divert on		
	<b>2</b>	Divert off		
<b>P196E</b> 1-16E Runner-4 1-8E	<b>ZONE ALARM SIA REPORTING CODE</b> Value from 1-14			
<b>P197E</b> 1E	<b>PANIC alarm SIA reporting code</b> Value from 1-14			
<b>P197E</b> 2E	<b>FIRE alarm SIA reporting code</b> Value from 1-14			
<b>P197E</b> 3E	<b>MEDICAL alarm SIA reporting code</b> Value from 1-14			

## MISCELLANEOUS 4+2 PROGRAM OPTIONS

<b>P195</b> 1E-4E	<b>MAINS &amp; BATTERY 4+2 REPORTING CODES</b>		
<b>P195E</b> 1E	<b>MAINS FAILURE 4+2 CODE</b> Enter a value of 2 digits (00-FF)		
<b>P195</b> 2E	<b>MAINS FAILURE RESTORE 4+2 CODE</b> Enter a value of 2 digits (00-FF)		
<b>P195E</b> 3E	<b>LOW BATTERY 4+2 CODE</b> Enter a value of 2 digits (00-FF)		
<b>P195E</b> 4E	<b>LOW BATTERY RESTORE 4+2 CODE</b> Enter a value of 2 digits (00-FF)		
<b>P195E</b> <b>5E-6E</b>	<b>MAINS &amp; BATTERY 4+2 REPORTING CODES</b>		
<b>P195E</b> 5E	<b>4+2 ALARM CODE FOR SYS TAMPER</b> Enter a value of 2 digits (00-FF)		
<b>P195E</b> 6E	<b>4+2 ALARM CODE FOR SYS TAMPER RESTORE</b> Enter a value of 2 digits (00-FF)		
<b>P195E</b> 7E-8E	<b>REMOTE ARM/DISARM 4+2 REPORTING CODES</b>		
<b>P195E</b> 7E	<b>4+2 CODE FOR REMOTE ARMING (FULL ARM OR STAY MODE ARM)</b> Enter a value of 2 digits (00-FF)		
<b>P195E</b> 8E	<b>4+2 CODE FOR REMOTE DISARM</b> Enter a value of 2 digits (00-FF)		
<b>P195E</b> 9E	<b>DURESS ALARM 4+2 REP. CODE (FULL ARM OR STAY MODE ARM)</b> Enter a value of 2 digits (00-FF)		
<b>P195E</b> 10E	<b>AUTOMATIC TEST 4+2 REPORTING CODE</b> Enter a value of 2 digits (00-FF)		
<b>P195E</b> 11E	<b>ARMED BY ARM BUTTON 4+2 REPORTING CODE</b> Enter a value of 2 digits (00-FF)		
<b>P195</b> E12E	<b>STAY MODE ARMING 4+2 REPORTING CODE</b> Enter a value of 2 digits (00-FF)		
<b>P195</b> E13E	<b>DISARMED BY ARM OR STAY BUTTON 4+2 REP CODE</b> Enter a value of 2 digits (00-FF)		
<b>P195E</b> 14-15E	<b>ARMED/DISARM BY KEY-SW 4+2 REP CODE</b>		
<b>P195E</b> 14E	<b>4+2 ARM BY KEY-SWITCH CODE</b> Enter a value of 2 digits (00-FF)		
<b>P195E</b> 15E	<b>4+2 DISARM BY KEY-SWITCH CODE</b> Enter a value of 2 digits (00-FF)		
<b>P195E</b> 16E	<b>TIME ZONE ARM FAILURE 4+2 REPORTING CODE</b> Enter a value of 2 digits (00-FF)		
<b>P195E</b> 17E	<b>KEYPAD PANIC ALARM 4+2 REPORTING CODE</b> Enter a value of 2 digits (00-FF)		
<b>P195E</b> 18E	<b>KEYPAD PANIC ALARM 4+2 RESTORE REP CODE</b> Enter a value of 2 digits (00-FF)		

<b>P195E</b> 19E	<b>KEYPAD FIRE ALARM 4+2 REPORTING CODE</b> Enter a value of 2 digits (00-FF)		
<b>P195E</b> 20E	<b>KEYPAD FIRE ALARM 4+2 RESTORE REP CODE</b> Enter a value of 2 digits (00-FF)		
<b>P195E</b> 21E	<b>KEYPAD MEDICAL ALARM 4+2 REPORTING CODE</b> Enter a value of 2 digits (00-FF)		
<b>P195E</b> 22E	<b>KEYPAD MEDICAL ALARM 4+2 RESTORE REP CODE</b> Enter a value of 2 digits (00-FF)		
<b>Panel Diagnostic &amp; Default Options</b>			
<b>P200E</b> 1E	<b>DISPLAY PANEL SOFTWARE VERSION NUMBER</b>		
<b>P200E</b> 2E	<b>DISPLAY KEYPAD ADDRESS NUMBER</b>		
<b>P200E</b> 3E	<b>DISPLAY AREAS ASSIGNED TO THIS KEYPAD</b> Displays Areas Assigned to this Keypad		
<b>P200E</b> 4E	<b>DISPLAY ACTIVE TIME ZONES</b>		
<b>P200E</b> 5E	<b>DISPLAY BATTERY VOLTAGE</b>		
<b>P200E</b> 6E	<b>WALK TEST MODE</b>		
<b>P200E</b> 7E	<b>WRITE TO EEPROM (DTU) BOARD</b>		
<b>P200E</b> 8E	<b>READ FROM EEPROM (DTU) BOARD</b>		
<b>P200E</b> 9E	<b>RESTORE USER &amp; INSTALLER CODES PLUS TELEPHONE NUMBERS TO DEFAULTS</b>		
<b>P200E</b> 10E	<b>RESTORE ALL FACTORY DEFAULTS</b>		
<b>P200E</b> 11E	<b>CLEAR ALARM MEMORY BUFFER</b>		
<b>P200E</b> 12E	<b>INITIATE A CALL TO THE CALL-BACK</b>		
<b>P200E</b> 13E	<b>INSTALLER</b>		
<b>P200E</b> 14E	<b>RSSI</b>		



# Installation Records

This section is to be used by the installer to record any changes made to the default values. There are three tables; Users, Zones and Phone Numbers.

## User Configuration

User Information				Wireless											
	User	P1E	P2E	P3E	P4E	P5E	P7E	P8E	P11E	P15E	P9E	P10E	P12E	P12E	P14E
#	Name	Code	Type	Area	Access	Privileges	Type	Privileges	Beeps	Panic2OP	TimeZ	Keypad	Output	ON	OFF
1															
2															
3															
4															
5															
6															
7															
8															
9															
10															
11															
12															
13															
14															
15															
16															

User Information								Wireless							
	User	P1E	P2E	P3E	P4E	P5E	P7E	P8E	P11E	P15E	P9E	P10E	P12E	P12E	P14E
#	Name	Code	Type	Area	Access	Privileges	Type	Privileges	Beeps	Panic2OP	TimeZ	Keypad	Output	ON	OFF
17															
18															
19															
20															
21															
22															
23															
24															
25															
26															
27															
28															
29															
30															
31															
32															
33															
34															
35															
36															
37															
38															
39															
40															
41															
42															



User Information								Wireless							
	User	P1E	P2E	P3E	P4E	P5E	P7E	P8E	P11E	P15E	P9E	P10E	P12E	P12E	P14E
#	Name	Code	Type	Area	Access	Privileges	Type	Privileges	Beeps	Panic2OP	TimeZ	Keypad	Output	ON	OFF
43															
44															
45															
46															
47															
48															
49															
50															
51															
52															
53															
54															
55															
56															
57															
58															
59															
60															
61															
62															
63															
64															
65															
66															
67															
68															

User Information								Wireless							
	User	P1E	P2E	P3E	P4E	P5E	P7E	P8E	P11E	P15E	P9E	P10E	P12E	P12E	P14E
#	Name	Code	Type	Area	Access	Privileges	Type	Privileges	Beeps	Panic2OP	TimeZ	Keypad	Output	ON	OFF
69															
70															
71															
72															
73															
74															
75															
76															
77															
78															
79															
80															
81															
82															
83															
84															
85															
86															
87															
88															
89															
90															
91															
92															
93															
94															

---

User Information								Wireless							
	User	P1E	P2E	P3E	P4E	P5E	P7E	P8E	P11E	P15E	P9E	P10E	P12E	P12E	P14E
#	Name	Code	Type	Area	Access	Privileges	Type	Privileges	Beeps	Panic2OP	TimeZ	Keypad	Output	ON	OFF
95															
96															
97															
98															
99															
100															

# Zone Configuration

		P121E	P122E	P123	P124E	P125E	P126E	P127E
ZONE	ZONE NAME	ASSIGNED AREA A/B	OPTION A	OPTION B	OPTION C	EOL	RESPONSE TIME	DETECTOR TYPE
1								
2								
3								
4								
5								
6								
7								
8								
9								
10								
11								
12								
13								
14								
15								
16								

**Note: For Runner 4 only zones 1-8 are available.**

---

## Phone Numbers

	P181E 8E	P182E 1-8E		P183E 1-8E
#	TELEPHONE NUMBER	FORMAT	RETRIES	REPORT OPTIONS
1				
2				
3				
4				
5				
6				
7				
8				



## **89CROW ELECTRONIC ENGINEERING LTD. (Crow) WARRANTY POLICY CERTIFICATE**

This Warranty Certificate is given in favor of the purchaser (hereunder the "**Purchaser**") purchasing the products directly from Crow or from its authorized distributor.

Crow warrants these products to be free from defects in materials and workmanship under normal use and service for a period of 24 months from the last day of the week and year whose numbers are printed on the printed circuit board inside these products (hereunder the "**Warranty Period**").

Subject to the provisions of this Warranty Certificate, during the Warranty Period, Crow undertakes, at its sole discretion and subject to Crow's procedures, as such procedures are from time to time, to repair or replace, free of charge for materials and/or labor, products proved to be defective in materials or workmanship under normal use and service. Repaired products shall be warranted for the remainder of the original Warranty Period.

All transportation costs and in-transit risk of loss or damage related, directly or indirectly, to products returned to Crow for repair or replacement shall be borne solely by the Purchaser.

Crow's warranty under this Warranty Certificate does not cover products that is defective (or shall become defective) due to: (a) alteration of the products (or any part thereof) by anyone other than Crow; (b) accident, abuse, negligence, or improper maintenance; (c) failure caused by a product which Crow did not provide; (d) failure caused by software or hardware which Crow did not provide; (e) use or storage other than in accordance with Crow's specified operating and storage instructions.

There are no warranties, expressed or implied, of merchantability or fitness of the products for a particular purpose or otherwise, which extend beyond the description on the face hereof.

This limited Warranty Certificate is the Purchaser's sole and exclusive remedy against Crow and Crow's sole and exclusive liability toward the Purchaser in connection with the products, including without limitation - for defects or malfunctions of the products. This Warranty Certificate replaces all other warranties and liabilities, whether oral, written, (non-mandatory) statutory, contractual, in tort or otherwise.

In no case shall Crow be liable to anyone for any consequential or incidental damages (inclusive of loss of profit, and whether occasioned by negligence of the Crow or any third party on its behalf) for breach of this or any other warranty, expressed or implied, or upon any other basis of liability whatsoever. Crow does not represent that these products can not be compromised or circumvented; that these products will prevent any person injury or property loss or damage by burglary, robbery, fire or otherwise; or that these products will in all cases provide adequate warning or protection.

Purchaser understands that a properly installed and maintained product may in some cases reduce the risk of burglary, fire, robbery or other events occurring without providing an alarm, but it is not insurance or a guarantee that such will not occur or that there will be no personal injury or property loss or damage as a result.

Consequently, Crow shall have no liability for any personal injury; property damage or any other loss based on claim that these products failed to give any warning.

If Crow is held liable, whether directly or indirectly, for any loss or damage with regards to these products, regardless of cause or origin, Crow's maximum liability shall not in any case exceed the purchase price of these products, which shall be the complete and exclusive remedy against Crow.





# How to Contact Us

---

[www.thecrowgroup.com](http://www.thecrowgroup.com)

[www.thecrowgroup.com/contact-worldwide.asp](http://www.thecrowgroup.com/contact-worldwide.asp)

[www.thecrowgroup.com/support-ask-us.asp](http://www.thecrowgroup.com/support-ask-us.asp)